



If the box is delivered with a rear panel, insert the panel in the grooves at the back of the side panels. Then, from the top to the bottom, push the rear cross bars with the dimensions 19 x 27 mm onto the metal bolts on the side walls. 5 bars in total!



In doing so, the holes in the rear bars must always point to the front.



Hang the base panels in the holes provided for this.





Press the beech wood perch bars onto the metal bolts on the upright side panels. 5 pieces per section. In doing so the notch on the bars must always point to the back.



Now the wire meshes are inserted. The folds must point downwards.



With the upright side panels, the plastic hooks for the top panel (cover) must be screwed only into the middle panels.







Arrange the front doors and front bars in the sections. In doing so, the sliding bolt must always point outwards.



The coloured front doors are placed in the top, middle and bottom box rows always on the left. In the second and fourth box rows from the top, always on the right of the section.



Fit the front bars with the 4 plastic hooks into the sections





10

Then from outside fit the front doors into the hooks.



Fit the front bars with front doors attached in all of the sections.



Insert the floors.





13

There are two variants of the middle doors (separating doors). Left-hand separating doors for the top, middle and bottom box sections, shown here on the left in the picture, and right-hand separating doors for the second and fourth box sections from the top, also shown here on the right in the picture.



14

Insert the separating doors to the right and to the left of the respective sections. Tip: The slider with the hole must always be able to be operated from the open side of the section!



17

Push the front doors to the front as shown in the picture.





16

Pull the front bar forward a little with the left hand and fit the separating door with the right hand. To do so, the dowel with the metal spring must first be inserted in the hole in the cross bar. Then the front dowel on the separating door must be guided into the groove of the front bar. Then move the separating door carefully to the side until this snaps into place in the hole in the front bar.

The separating door engages in the notch below in the perch bar.



17





Fit the dividing piece. The dowel with the metal spring is inserted into the hole of the cross bar and pressed up. Now carefully move the dividing piece to the side until it snaps into the two holes of the perch bar.



18

The sectioned box is fully assembled. Once the box has been fully assembled and aligned it must be firmly screwed to the rear wall





The coloured infill of the front door can also be opened. Thereby the pigeon can also be removed from the section from the front.



The separating door in the middle of the section can now also be swivelled upwards.



When, for example, there is a bowl present and young birds need to be taken out.